Notes:
Code 1. Random patterns flashing on rear only. Director inputs will override this.
Code 2. Random front and rear, with rear replaced by director if director switches active.
Code 3. Random front and rear and flash alley lamps. Ignore director inputs.

ITEM	QTY	PART NO.	DESCRIPTION



CCT should only need a 100ma or less.

INPUT SECTION

CONTROLLER SECTION

OUTPUT SECTION



Suggested Panel Layout



Physical Led Module Layout



SOFTWARE
HARDWARE
ANY-WARE
GLAISTER CONSULTING

REV	ECO No.	DATE	BY	DESCRIPTION

DR.	lpg
CH.	lpg
DATE	
SCALE	nts

Emergency Vehicle Lightbar Controller

A2 LIGHTBAR.DWG DWG NO. REV – SHT 1/1